



Into Education?



Into Sport?



Into Music?



Into Movies?

Once your *eircom* **broadband** service has been activated, use the following ADSL filter install guide overleaf to help you get started quickly and easily.



**eircom broadband**

There's no stopping you.

# ADSL Filter Install Guide

1. Plug microfilters into your telephone sockets. Microfilters need only be plugged into the sockets on the line that *eircom broadband* is being supplied on.

The microfilters prevent the different signals of the ADSL service and the standard voice telephony service interfering with one another on the same line. You must plug all communications equipment (including telephones and fax machines) into the microfilters, as well as the connecting cable from your ADSL modem.

2. If the phone jack where you plan to plug in your modem is already connected to a telephone or telephone device, use the dual filter to connect both the modem and your telephone device to the same telephone wall jack.
3. Connect and install your ADSL modem, referring to the instructions provided in the manufacturer's user guide or manual.

For further instructions on how to use the microfilters in conjunction with *eircom broadband* and your ADSL modem log on to [http://www.eircom.ie/bveircom/pdf/netopia\\_installation\\_guide.pdf](http://www.eircom.ie/bveircom/pdf/netopia_installation_guide.pdf)


Should you have any problems or questions regarding *eircom broadband*, please call 1530 555 444\* if you are an *eircom broadband home starter* customer. If you are a *home plus* or *eircom broadband business* customer please call 1890 260 260\*\*.

\* Calls cost 33.00c per minute inc. VAT (27.27c ex. VAT).

\*\*Calls cost 5.02c inc. VAT (4.19c ex. VAT).


A minimum call charge of 6.35c inc. VAT (5.24c ex VAT) applies to all calls. VAT is charged at 21%.

Telephone Jack



Line Sharing Filter

Telephone Socket



ADSL Modem



**eircom broadband**  
There's no stopping you.